

Flexcom bike tracker

FB122 2G



Short installation and operating instructions

Full version: <https://nyomkovetes.net>



Based on its design and mounting, the device is primarily designed to track bicycles - as a result, its users are primarily vehicle owners (adults or children).

Settings that affect the operation of the device can only be changed from another device (smartphone, computer) with the help of our software application - so users can be sure that the device always works according to the parameters they specify.

1. Parts of the device




1. LED
2. Reset button
3. USB C connector
4. Screw hole

Technical data

Size	85mm X 41mm X 22.3mm
Weight	100g
Network	2G 850/900/1800/1900
Accuracy	5m
Input voltage	5V - 1.0A
Battery	Rechargeable 3.7V 2000mA lithium battery
Charging time	2-3 óra
Standby time	15 nap

2. Startup

The device is delivered ready for use with a built-in SIM card that can be used anywhere in the world. When the battery is charged, the device switches on automatically and works continuously - it only switches off when it is discharged. The device can be mounted under the bottle holder of the bicycle with the individual safety screws included in the package.



3. Battery charging

The device battery needs to be charged at different intervals depending on the intensity of use. The appropriate charger and micro USB charging cable are included in the package.



Charging takes 2-3 hours, during which time the LED indicator lights up red. When the device is fully charged, the light turns off.



Charging voltage and current: 5V / 1A.

Disconnect the device from the charger after charging.

4. Install application

If you have subscribed to a software service from your device vendor, then:

- For Android phones, you can install the app by scanning this QR code.



- For iPhone devices, use this code.



You need an active internet connection on your phone or computer to use the software!

Desktop version:

<https://gpspositions.net/map>

5. Device states

LED displays inform the user about the operation and status of the device.



LED	Signal	Device status
Red	On Off	Charging Charged
Blue	On Flashes Off	Sat connection on No sat connection Device in sleep mode or off
Green	On Flashes Off	GSM connection on No GSM connection Device in sleep mode or off

Flexcom bike tracker

FB122 2G



Operating instructions and further information

See more: wiki.nyomkovetes.net



Flexcom®
GPS Tracking Solutions

Place of origin: Hungary

Manufacturer/ distributor

FLEXCOM COMMUNICATION LTD.

Address: 2151 Fót, Szent Imre str. 94. Hungary

Phone: +36 1 769 1005

Email: info@flexcom.hu

Website: <https://flexcom.hu>

Mobils 1: +36 70 3333 525

Mobils 2: +36 70 3333 527

Phone service: (Monday–Thursday) 9.00–15.00

Safety information

The appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

When using a GPS device, the following safety precautions must be observed to ensure proper operation of the device:

- **Power supply:** Operate the device only with the specified power supply voltage. Check that the power source meets the technical requirements of the device and only use chargers recommended by the manufacturer.
- **Storage:** Keep the device in a dry and well-ventilated environment. Do not store in a damp or humid location as this may damage the internal circuits.
- **Temperature:** Avoid extreme temperatures. It may cause the device to malfunction or fail if left in an overheated (above 50°C) or overcooled (below 0°C) environment.

- **Handling:** Handle the device with care. Avoid shock, strong vibration and mechanical shock, which may damage the device.
- **Cleaning:** Use a dry, soft cloth to clean the device. Do not use chemicals, cleaning agents or solvents. Always disconnect the device from the power source before cleaning.
- **Disassembly:** Do not attempt to disassemble or modify the device. Disassembly may not only invalidate the warranty, but may also cause the device to malfunction.
- **Child protection:** Keep the device out of the reach of children, especially as it contains small parts that could cause choking if swallowed.
- **Environmental awareness:** Dispose of the device and its components in accordance with local waste disposal regulations. Do not dispose of electrical and electronic waste in household waste.
- **Installation:** The device must only be installed by a qualified person. The device must be installed in accordance with the regulations.

- **Interference:** This device emits radio frequency signals—do not use where these signals may cause interference with other devices.
- **Battery use:** If you notice that the operating time is significantly reduced, have the battery replaced as soon as possible to avoid malfunction. Have the battery replaced by a qualified service technician - contact your product dealer for information.
- **Programming:** Always set up and program the device according to the manufacturer's instructions.
- **Warning for expectant mothers:** Due to the radio frequency signals emitted by the device, it is recommended that expectant mothers use the device at a distance of at least 20-30 cm and avoid direct contact with the abdominal area.
- **Emergencies:** The GPS device is not a substitute for traditional emergency call systems. In the event of an emergency, use the communication channels provided by local authorities.

Declaration of Conformity and Certificate

Shenzhen Juneo Technology Limited, declares under its sole responsibility that the product identified above is in compliance with the essential requirements and other relevant provisions of the following directives:

- 2014/53/EU - Radio Equipment Directive (RED)
- 2014/30/EU - Electromagnetic Compatibility Directive (EMC)
- 2011/65/EU - Restriction of Hazardous Substances (RoHS)

Guarantee

The product is covered by a 2-year warranty, valid from the date of purchase. The warranty covers material and manufacturing defects that occur under normal use.

The warranty does not cover:

- damage resulting from improper use,
- physical damage and
- unprofessional repair or modification.

In warranty matters, please contact the place of purchase or the distributor. The original proof of purchase is required to validate the warranty.

Related documents

Declaration of conformity, standards, certificates; environmental and detailed technical and usage information: <https://wiki.nyomkovetes.net>

	This symbol indicates that this product should not be disposed of with household waste at the end of its life. Please hand it in at a designated recycling point or use the services of your local
CE	The CE marking shows that the product complies with the safety, health and environmental requirements of the
RoHS	RoHS compliance indicates that the product does not contain hazardous substances such as lead, mercury or